

# Calling Card Telephone IP 510 MAG User Manual



We thank you for buying our Calling Card Telephone IP 510 MAG and wish you success and enjoyment in using it.

The telephone is planned for easy operation by the client without any need of special explanation apart from looking at the instructions displayed on the front of the phone and following them.

We're sure that this telephone will be a good replacement to the existing system, using regular phone and random collection.

When using a calling card, the customer enjoys low rates for international and an intercity calls through the Prepaid Platform.

In order to have the most advantages of the Calling Card Telephone IP 510 MAG, please read the installation and operation instructions.

For operating instructions and technical support, please contact customer service.



## **Reliability of the product:**

The Calling Card Telephone IP 510 MAG is designed to be used as a medium connected to the country's communication system. The manufacturer won't be responsible for any damage caused due to improper use of this telephone and/or improper installation.

## **Humidity and dust:**

Avoid using the Calling Card Telephone IP 510 MAG in especially humid and dusty locations, otherwise some components may be damaged.

## **Comments:**

1. You can connect the Calling Card Telephone IP 510 MAG to the PSTN telephone line 48-60 volt DC 20-120 mA current line.
2. There will be no refund for prepaid cards.
3. Expiry date of the card is printed on it.

## **The package contains:**

1. Calling Card Telephone IP 510 MAG
2. Programming key
3. Warranty document
4. Manual for user

## Installation:

### Position in which to install the phone:

Install the telephone vertically, (straight).  
Name of the owner and operating instructions should be installed close to the phone and easy to read.

1. Bore 4 holes in diameter of 7mm according to the place of the screws in the back of the phone and at a height of 1.2 Meters from the ground or floor.
2. Connect Alkaline 9V battery / optional / .
3. Connect the telephone to the country's phone network, connect the Calling Card Telephone IP 510 MAG to the line socket in the wall.
4. Lift the Handset.
5. The display will show :

**Swipe The Card or  
Press "A"**



Function buttons: **A**, **B**, **C** and **D**

## Placing a call (magnetic calling call operation)

1. Lift the handset and listen for dialing tone.
2. Swipe the magnetic calling card.
3. Listen to instructions from the Prepaid Platform.
4. Upon hearing that your card PIN number has been accepted, enter your destination number, including country code in the case of an international call, and city code in the case of an inter-city call.

## Placing a call (manual operation)

1. Lift the handset and listen for dialing tone.
2. Press the fast-dial button **A** to call Prepaid Platform.
3. Listen to instructions from the Prepaid Platform and enter PIN number from card when requested to do so.
4. Upon hearing that your PIN number has been accepted, enter your destination number, including country code in the case of an international call, and city code in the case of an inter-city call.

## Follow on Call

In case of a need to dial an extra number, once the pin number was given already by the subscriber, there is no need to place back the handset. The only need in such a case would be to push first the button **B** follow the written instruction on the display, than dial the complete destination number.

## Redial function


For redialing the same number, do not replace the handset, but only press fast-dial button **C**

## Volume control function

Butten **D** serves to increase / decrease the volume.

## Placing an emergency or toll-free call

1. Lift the receiver and listen for dialing tone
2. Dial a number



1. The user has to operate according to the recorded and displayed instructions.

The image shows a large instruction panel for a public telephone. At the top, it reads "MAGNETIC CALLING CALL PUBLIC TELEPHONE". Below this, there are three main steps: "Pick Up" (with a telephone handset icon and an upward arrow), "Swipe the card and dial PIN" (with an icon of a hand swiping a card and a keypad), and "Wait for Instruction" (with a telephone handset icon). To the right of these steps are four red triangular markers labeled A, B, C, and D, each pointing to a specific instruction: "A Tool Free", "B Customer Service", "C Adtional Call", and "D Volume". At the bottom of the panel, it provides manufacturer information: "Manufacturer: Peryphon Ltd. PTT. No: 13-1218-0-101541. Model: IP-510CC Serial Number: 020010".


2. Instruction for using prepaid telephone cards ( For example ):

The image shows a prepaid telephone card instruction card. It is divided into three numbered sections: 1. "Dial: Public: -free phone number- Mobile Connes: 2-phone number- Mobile Orange: 3-phone number-"; 2. "After the beep enter your code number + #: 56342543"; 3. "Place a call: Country Code + Area Code + Phone number + #". To the right of these sections, there is a "Customer Service:" section and a "Notice:" section with several lines of small text. At the bottom right, there is a small logo with the letters "N" and "S".


## Setup:

For entry to SETUP MENU:

1. Lift the Handset
2. Display is showing:



3. Open the phone with the key, push the **PROGRAMMING** button (The black button is located on the main circuit) and lift the handset. After 2 sec. release the **PROGRAMMING** button.
4. After display showing:



5. To scroll down on menu use button **D**, to scroll up use button **A**

## SETUP MENU

### Button A function

Function	Display	Note
Button A functions	Bottom "A" Off	Using button A to fast dial Access number , Support number or disable this button. Press <b>*</b> to switch Saved automatically.

### Access number

Function	Display	Note
Access Number. 22 digits max.	Prov. No: xxxxxxxxxxxx	Enter Access Number. For save press <b>B</b> For pause 2 sec (displayed P) press <b>C</b>

### Support number

Function	Display	Note
Support (Service) number. 22 digits max.	Support No: YYYYYYYYYY	Enter Support Number. For save press <b>B</b> For pause 2 sec (displayed P) press <b>C</b>

### Delay Time

Function	Display	Note
Delay Time, 0-39 sec.	Delay Time 01	Delay time between dialing Access number and card (PIN) number. For change press <b>*</b> . Saved automatically.

### Incoming Call Keyboard Off

Function	Display	Note
Using Keyboard after Incoming Call	In.Call Keyboard Off	Keyboard can be used after Incoming Call. For change press <b>*</b> . Saved automatically.

## Reader On

Function	Display	Note
Magnetic card reader On/Off	Reader On	For change press <b>*</b> . Saved automatically.

## Emergency and Free Numbers

Function	Display	Note
Contains 10 free numbers, each of 4 digits/symbols Fr01- Fr10	Free No. Fr01: aaa ..... Fr10: zzz	Free prefix or emergency service. Opened to free dialing. Changing: Enter number. Press <b>B</b> - Save to memory. Press <b>C</b> to clear an existing prefix. Saved automatically.

## Dialing mode: Tone (DTMF) or Pulse

Function	Display	Note
Dialing Method	Dialing Mode: Tone Dialing	Access number dialing method Press <b>*</b> to change Dialing Mode. Saved automatically. Tone Dialing -default

## Start Tone ( Lift handset PAYPHONE Tone )

Function	Display	Note
Start Tone	Start Tone Off	Function On/Off. Press <b>*</b> to switch on/off (saved automatically).

## Incoming Call P.Tone ( Incoming Call PAYPHONE Tone )

Function	Display	Note
In.Call P.Tone	In.Call P.Tone On	Function On/Off. Press <b>*</b> to switch on/off (saved automatically).

## Button B On/ Off

Function	Display	Note
Using button B	Button B On/Off On	Press <b>*</b> to change. Saved automatically.

## Button B "Follow on Call" special signaling

Function	Display	Note
Dialing special "Follow on Call" signal to provider, each of 5 digits/symbols	Button B: ## ___	Enter digits/symbols. For save press <b>B</b> For pause 2 sec (displayed P) press <b>C</b>

## Button C On/ Off

Function	Display	Note
Using button C	Button C On/Off Off	Press <b>*</b> to change. Saved automatically.

## Button C "Redial" special signaling (not used)

Function	Display	Note
Dialing special "Redial" signal to provider, each of 5 digits/symbols	Button C: 11 ___	Enter digits/symbols. For save press <b>B</b> For pause 2 sec (displayed P) press <b>C</b>

## Programming ( part 3)

9

### Language

Function	Display	Note
Language	English	Press <b>*</b> to change. Saved automatically.

### Dial Pin only/ Dial Pin + #

Function	Display	Note
PIN Dialing	Dial Pin pnly	Press <b>*</b> to change. Saved automatically.

### DTMF parameters: Make

Function	Display	Note
Time making DTMF automatically, mS	Make 0200	Press <b>*</b> to switch this time between 100 – 500 mS Saved automatically.

### DTMF parameters: Break

Function	Display	Note
Pause time between automatic DTMF's , mS	Break 0200	Press <b>*</b> to switch this time between 100 – 500 mS Saved automatically.

### Hang Up Tone On / Off

Function	Display	Note
Hang up tone	Hang Up Tone Off	Press <b>*</b> to switch. Saved automatically.

### Hang Up Tone special signaling

Function	Display	Note
Hang up tone Special signalling	Hang Up Tone *1	Enter number. Saved automatically.